




# LG Optimus L9 P769 Headphone Jack Replacement

This guide will allow you to remove the Audio jack if it becomes damaged or inoperable.

Written By: Paul





## INTRODUCTION

You will need to know how to remove the motherboard in order to complete this guide.





## Step 1 — Motherboard Removal



- Pry the storage unit from the frame.
- Remove the motherboard from the frame.

## Step 2 — Remove the Audio Jack



- Pry the Audio Jack from the frame. It will come loose easily.

To reassemble your device, follow these instructions in reverse order.

